

## Loading CP179 & CP209 with a new operating system:

1. Unzip the folder and locate the six files inside the folder.
2. Move the six files to the root directory of a USB flash drive (memory stick), **Do Not place files in a folder.**
  - a. Note: Move six files only, not folder onto the USB root directory, unit will not look inside of folders when in programming mode.
2. Turn OFF unit power, place USB flash drive into front USB port, located to the right of the keyboard, above the cheek block.
3. Turn ON power, unit will auto recognize software and start to load

**\*\*Load will take up to 18 minutes; Do not turn OFF unit, Do not remove USB flash drive while files are loading.\*\***

During the software load, the screen will alternate between displaying "ERASING" or "WRITING", you will see numbers incrementing on the screen as the files are being written into the CP179 or CP209.

4. Unit can take up to 18 minutes for files to load
  - a. If load take longer than 20 minutes, turn off unit wait 20 seconds and turn power back on to retry software load.
5. Display window will show the word "COMPLETE" near the bottom of screen when load is complete, turn power OFF and remove flash drive.
6. Turn power ON, test unit for proper operation.

If your CP unit still has a problem, please contact Kawai at 800.421.2177, press #1 for service department.